



Burden

Spacing

New Crest (after blasting)

Hole Diameter

Stemming Height

Bench Height

Free Face

Stemming Plug

Crest

Explosives Column

Crest Burden

Hole Length

Sub-drill

Face Angle

Floor